WALKER & WILLIAMS

# U-74 Ukulele Strap

Many ukes do not come with any way to attach a strap. Our U-74 uke strap is designed to be used with ukuleles that do not have strap buttons. Here's how to attach the U-74 to your uke.

Start by threading the shorter piece under the strings at the headstock

Pull the whole buckle through the slot in end of the shorter piece

Then pull the belt loop through the same slot

Now it should look like this

Buckle the main strap to the shorter piece

Hook the nylon hook onto the bottom part of the sound hole

Loop the nylon cord around the lower bout

Use the adjuster to size the nylon cords to your uke

The completed strap should look like this

Walker & Williams Premium Leathers • Santa Barbara, California • www.walkerandwilliams.com • 800-354-5351